
WARNING:


Fingers can be pinched when adjusting clamps with drum key.


Operate carefully. Be Careful around pipe ends, inside pipes and screw ends.


Metal shavings, etc. may injure your fingers


1 CHECK INCLUDED ITEMS























NOTE:

Loosen or tighten the screws on the clamp with drum key as shown partial enlargement. Adjust the height of the Side Arms with drum key as needed.



5. Attach Side Arm (L1) to clamp on Pillar (L1). 6. Attach Side Arm (R) to clamp on Pillar (R2).

7. Attach Side Arm (R) to clamp on Pillar (R1).


8. Attach Side Arm (L2) to clamp on Pillar (L1).

Attach the pad mounts to the mount holders on the Center Pipe 1, Side Arm (L2), Side Arm (R), and firmly tighten the respective wing nuts 1.

NOTE:

Loosen or tighten the wing nuts on the mount holder as shown in the partial enlargement.

Move the mount holders as needed, and firmly tighten the respective wing nuts 2.




NOTE:

Loosen or tighten the wing nuts on the mount holder as shown in the partial enlargement.

ATTACH THE DRUM PADS


- 1. Loosen the wing nuts on the drum pads.
- 2. Attach the drum pads to the pad mounts, and firmly tighten the wing nuts on the drum pads.





ATTACH THE CYMBAL PADS 1. Remove the wing nut and felt Crash 1 Ride Wing Nut (Boom Arm) (Boom Arm) washer from the cymbal tilter. Crash 2 Felt Washer 2. Place the cymbal pad, felt washer and wing nut assembly Wing Nut Hi-Hat as shown, then tighten the wing nut to obtain an appropriate amount of sway. 3. Adjust the cymbal pad position with the wing nut. NOTE: Tighten the bolt with the hexagon key as shown Boom Arm Hi-Hat Arm for Bolts


ASSEMBLE THE KICK



- 2. Adjust beater position and tighten the beater with the drum key.
- 3. Attach foot pedal to the kick pad.
- 4. Adjust beat position and tighten the wing nut.

NOTE:

Position one beater centered on the kick pad or two beaters equally apart from the center as shown.



CONNECT THE PADS TO THE DRUM MODULE

ATTACH THE DRUM MODULE

- 1. Connect the cable to the drum module with hand screws as shown here.
- 2. Attach drum module to the mount holders on Side Arm (L1), and firmly tighten wing nut

NOTE:

 $Loosen\ or\ tighten\ wing\ nuts\ on\ mount\ holder\ as\ shown\ in\ the\ partial\ enlargement.$

Move mount holders as needed, and firmly tighten the respective wing nuts.

