



# M665B Symphonic Chimes



**E50270010**

M665BF M665B Less tubes




**E7341**

E7341 Upright tube




**E7342**

E7342 Top Support



**E73451**

E73451 Leg casting L/R



**P1447**


P1447 3" Locking caster



**E7289**


E7289 Chime hanger bar, natural

E7290 Chime hanger bar, sharp



**E7346**

E7346 Lower crossbar



**E7216**

E6216 Diagonal brace

E2357 1/4-20x3/4 cap scrw for bottom

E2358 1/4-20x1/2 cap screw for top

**E2580T** Set screw kit (12pcs) for frame.

contains: (8) E2580 5/16-18 x 3/8

(4) E2579 5/16-18 x 5/8

(not incl) **E0372** 5/32" Allen wrench


(not incl)

(not incl)


M655B parts, cont.




**E73481** Pedal/pullrod assy




**E32262** Lower pullrod  
(Includes E9487 knob and E3235 pullrod stud)



**E9487**  
E9487 1/4-20 plastic knob



**E34741**  
E34741 Upper pullrod assy



**E7354** Damper box assembly



**E73211** Damper box grille

**E7351** Side casting

**E73211** Damper box grille

**E73031** Top damper board

**E73041** Middle damper board

**E7312** Chime roller bracket


**E1433** #6x1 tapping screw

**E73051** bottom damper board

**E7313** Chime lever assy.


**E7324T** damper felt, 10pk

**E2359** 1/4-20x1 cap screw (16 per)



**E7313**

E7313 Chime lever assembly




**E7351**

E7351 Side casting (1)



**E4727T**

E4727T Chime cable kit (10pk)



**E7295FUL**

**E7295FUL** Set of tubes for M665B, A=442  
**E7295FULW0** Set of tubes for M665B, A=440  
**E7295xxx** Individual bars for M665B  
 ex, E7295CN5 = lowest C natural.  
 ex, E7295CS5 = C sharp 1/2 step up.