



# M31 Windsor II



## E50250050


**E50250050** Frame with hardware  
Comes with posts and insulators & leg straps.  
Also includes:

- E4061** Resonator plate (4)
- E4065** Resonator rubber (4)
- E3809** HE Resonator mount (2)
- E39451** Handle, painted.



## E3844

**E3844** Resonator assy, plain.



## E3845

**E3845** Resonator assy, sharp.



## E0905

**E0905** End post (8 per instrument)

## E0900T

**E0900T** Saddle post (10pk) 108 per instrument.




## E1902V

**E1902V** Cord spring (2pk)  
Order 2 packs for one instrument.

## E0305T

**E0305T** Post insulator (10pk) 116 per inst.



**E4441V** Green bar cord (2pk)



## E3804FUL

- E3804FUL** Set of bars for M31, A=442
- E3804FULW0** Set of bars for M31, A=440
- Standard tuning changed from A=440 to A=442 on 1/1/94
- E3804xxx** Individual bars for M31
- (Ex: Middle C is E3804CN4, 1/2 step up is E3804CS4)

M31 parts, cont.



**E6161**



**E9784**




**E6160**

- E6161** Knob w/stud 5/16-18
- E9784** Thru hole knob 5/16-18
- E6160** Leg extension

- E38611** HE Leg assy (includes E2590)
- E38601** LE Leg assy (includes E2590)

To convert to adj ht legs, order:

qty	Part #	description
1	<b>E38615</b>	HE leg assy
1	<b>E38605</b>	LE leg assy
4	<b>E6160</b>	Leg extension
2	<b>E0140</b>	Caster, plain
2	<b>E0141</b>	Caster, brake
4	<b>E6161</b>	Knob w/ stud
4	<b>E9784</b>	Thru hole knob
2	<b>E9520</b>	Velcro strap 16"




- E4074** HE leg brace
- E4069** LE leg brace
- E4491** Add on Carrier Bracket (on frame)
- E2590** Wing Nut
- E2460** 1/4-20 lock nut

E2590 connects brace to leg assy  
E2460 connects brace to Carrier Bracket



**E2590**



**E0140**

- expandable stem casters
- E0140** plain caster for adj ht inst
- E0141** brake caster for adj ht inst
- E0135** plain caster for fixed ht inst
- E0136** brake caster for fixed ht inst