



# M48 Pro Traveler Vibraphone



**E3646**

- E3646 Motor and control assy
- E36191 Motor w/connector
- E3634 Motor control unit
- E3617 ON/OFF switch
- E3632 Small potentiometer
- E3621 Control box mounting bracket
- E3630 Speed control knob
- E30601 Motor Panel w/Pins




**E3630**



**E9436**

- E9436 Plain resonator and pulsator assembly
- E9438 Plain pulsator shaft assembly



**E3497**

- E3497 Belt cover plate



**E9437**

- E9437 Sharp resonator and pulsator assembly
- E9439 Sharp pulsator shaft assembly
- E3154 LE bearing bracket
- E3156 Center bearing brkt
- E3155 HE bearing bracket
- E3157 Nyliners
- E9487 1/4-20 plastic male knob



**E3631**

- E3631 Motor Pulley



**E0412**

- E0412 Motor mounting ring




**E0408**

- E0408 Belt




**E9487**

E9487 fastens resonator sections as shown below.




**E33281**

- E33281 Resonator pulley



- E9457 #1 Rail assembly (closest to player)
- E9459 #2 Rail assembly
- E4491 Add on carrier bracket (for diag. braces)
- E9461 #3 Rail assembly
- E9463 #4 Rail assembly (farthest from player)
- E3017 Hinge assembly (same on all 4 rails)

M48 parts, cont



**E9490**


**E9490** Crossbar assembly

- A** **E9494** Low end leg brace
- B** **E94862** Low end crossbar brace
- C** **E94565** High end crossbar brace
- D** **E9493** High end leg brace
- P1354** Plastic T handle knob
- E4491** Add-on carrier bracket
- E2590** Wing nut (braces to frame)




**E0900T**

**E0900T** Saddle post (10 pk)  
40 per instrument




**E0901T**

**E0901T** Hook Post (10 pk)  
40 per instrument



**E0905**

**E0905** End post (rail 1&4)  
4 per instrument




**E0912**

**E0912** End Post (rail 2&3)  
4 per instrument




**P1534**

**P1534** T handle



**E0117**

**E0117** Caster



**E0300T**


**E0300T** Post Insulator (10 pk)  
88 per instrument

Parts of E9471 low end assembly

- E3456** Rail Bracket for #1
- E34411** Rail Bracket for #2
- E34401** Rail Bracket for #3
- E9472** Rail Bracket for #4
- E3216** LE damper bracket
- E3125** LE resonator plate, plain
- E3126** LE resonator plate, sharp
- E3127** LE resonator rubber (2)
- E3131** Fiber plate (2)
- E0302** Insulator (4)

Parts of E9474 HE assembly

- E3547** HE rail bracket for #1
- E9475** HE rail bracket for #4
- E0302** Insulator (2)



**E9471**

**E9474**

**E9478**

**E9479**

**E9478** LE leg  
**E9471** LE assy

**E9479** HE leg  
**E9474** HE assy

**P1534** Plastic T-handle

P1534 connects leg assemblies to end pcs.




**E1902V**


**E1902V** Cord Spring (2 pk)  
Order 2 packs for one instrument

**E4441V** Green bar cord (2 pk)


M48 parts, cont



**E94961** Pedal and Pulrod assy  
**P1534** Female T handle (not shown)  
 (P1534 connects the pedal to crossbar)  
**E9487** Male plastic knob  
 (E9487 secures lower pullrod to upper)  
**E7323T** Pedal felt (10 pk)



**E34741**  
**E34741** Upper pullrod



**E3476** Low end damper arm  
**E3216** Mounting clip for E3476  
**E3477** High end damper arm  
**E3217** Mounting clip for E3477



**E9487**




**E2477**

**E2477** Wing nut



**E3206**

**E3206** Felt Washer




**E32031**

**E32031** Damper adj nut




**E32111**

**E32111** Damper spring




**E3213**

**E3213** Damper spring bracket



**E3279**

**E3279** Damper felt 1/2" X 1 1/2" X 51"



**E37762FUL**


**E37762FUL** Full set of bars for M48 tuned to A=442

**E37762FULW0** Full set of bars for M48 tuned to A=440

Standard tuning changed from A=440 to A=442 on 1/1/94

**E37762xxx** Individual bars for M48

(Ex: Middle C = E37762CN4, 1/2 step up is E37762CS4)



**E9450**

**E9450** Damper bar assembly

**E9487** Male plastic knob

**E3476** Low end damper arm

**E3477** High end damper arm



**E9487**