



M48S Pro Traveler Vibraphone



E3646

- E3646 Motor and control assy
- E36191 Motor w/connector
- E3634 Motor control unit
- E3617 ON/OFF switch
- E3632 Small potentiometer
- E3621 Control box mounting bracket
- E3630 Speed control knob
- E30601 Motor Panel w/Pins




E3630



E94361

- E94361 Plain resonator and pulsator assembly
- E9438 Plain pulsator shaft assembly




E3497

- E3497 Belt cover plate



E94371

- E94371 Sharp resonator and pulsator assembly
- E9439 Sharp pulsator shaft assembly
- E3154 LE bearing bracket
- E3156 Center bearing brkt
- E3155 HE bearing bracket
- E3157 Nyliners
- E9487 1/4-20 plastic male knob



E3631

- E3631 Motor Pulley



E0412

- E0412 Motor mounting ring




E0408

- E0408 Belt




E9487

E9487 fastens resonator sections as shown below.




E33281

- E33281 Resonator pulley



- E9457 #1 Rail assembly (closest to player)
- E9459 #2 Rail assembly
- E4491 Add on carrier bracket (for diag. braces)
- E9461 #3 Rail assembly
- E9463 #4 Rail assembly (farthest from player)
- E3017 Hinge assembly (same on all 4 rails)

M48S parts, cont



E94901


E94901 Crossbar assembly

- A** **E9494** Low end leg brace
- B** **E94862** Low end crossbar brace
- C** **E94565** High end crossbar brace
- D** **E9493** High end leg brace
- P1354** Plastic T handle knob
- E4491** Add-on carrier bracket
- E2590** Wing nut (braces to frame)




E0900T

E0900T Saddle post (10 pk)
40 per instrument




E0901T

E0901T Hook Post (10 pk)
40 per instrument



E0905

E0905 End post
4 per instrument
Used on rails 1 & 4




E0912

E0912 End Post
4 per instrument




P1534

P1534 T handle



E0117

E0117 Caster



E0300T


E0300T Post Insulator (10 pk)
88 per instrument

Parts of E9471 low end assembly

- E3456** Rail Bracket for #1
- E34411** Rail Bracket for #2
- E34401** Rail Bracket for #3
- E9472** Rail Bracket for #4
- E3216** LE damper bracket
- E3125** LE resonator plate, plain
- E3126** LE resonator plate, sharp
- E3127** LE resonator rubber (2)
- E3131** Fiber plate (2)
- E0302** Insulator (4)

Parts of E9474 HE assembly

- E3547** HE rail bracket for #1
- E9475** HE rail bracket for #4
- E0302** Insulator (2)



E94782 LE leg
E9471 LE assy

E94792 HE leg
E9474 HE assy

P1534 Plastic T-handle

P1534 connects leg assemblies to end pcs.




E1902V

E1902V Cord Spring (2 pk)
Order 2 packs for one instrument

E4441V Green bar cord (2 pk)

Used on rails 2 & 3


M48S parts, cont




E94962 Pedal and Pulrod assy
P1534 Female T handle (not shown)

(P1534 connects the pedal to crossbar)

- E9487** Male plastic knob
(E9487 secures lower pullrod to upper)
- E7323T** Pedal felt (10 pk)



E3474
E3474 Upper pullrod



E3476 Low end damper arm
E3216 Mounting clip for E3476
E3477 High end damper arm
E3217 Mounting clip for E3477



E9487




E2477

E2477 Wing nut



E3206

E3206 Felt Washer




E32031

E32031 Damper adj nut




E32111

E32111 Damper spring




E3213

E3213 Damper spring bracket




E3279

E3279 Damper felt 1/2" X 1 1/2" X 51"



E9450

E9450 Damper bar assembly
E9487 Male plastic knob
E3476 Low end damper arm
E3477 High end damper arm



E37761FUL

E37761FUL Full set of bars for M48S tuned to A=442

E37761FULW0 Full set of bars for M48S tuned to A=440

Standard tuning changed from A=440 to A=442 on 1/1/94

E37761xxx Individual bars for M48S

(Ex: Middle C = E37761CN4, 1/2 step up is E37761CS4)



E9487